

# PRO RZ251W

Pro1 Technologies

P.O. Box 3377  
Springfield, MO 65804

Toll Free : 888-776-1427  
Web: www.pro1iaq.com  
Hours of Operation: M-F 9AM - 6PM Eastern

Table of Contents	Page	Page	
Table of Contents	1	10-11	
Quick Reference	2	12	
Mounting Locations	3	13-14	
Mounting Options	4-6	15	
Installing Batteries	7-8	16	
Communication Setup	9	17-18	
		Specifications (Zoning)	19

This manual covers the following models:

- **RZ251W** (For use with T955WH remote sensing thermostat and the Z955W zoning system).

### Congratulations on purchasing our Wireless System.

This remote sensor was designed to the highest reliability and ease of use standards. Thank you for choosing our quality products.

**A trained, experienced technician must install this product.**

Carefully read these instructions. You could damage this product or cause a hazardous condition if you fail to follow these instructions.

Una version en español de este manual se puede descargar en la pagina web de la compania.

### Caution: Equipment Damage Hazard

Do not operate the cooling system if the outdoor temperature is below 50°F (10° C) to prevent possible compressor damage.


1 ® U.S. Registered Trademark. Patents pending  
Copyright © 2018 All Rights Reserved.

Rev. 1820

## Mounting Locations

### Recommended Wall Mounting Locations


The remote sensor should be mounted or placed approximately 4 to 5 feet above the floor. Select an area with average temperature and good air circulation.



### Do not mount or place Remote Sensors in locations:

- Close to hot or cold air ducts
- That are in direct sunlight
- With an outside wall behind the thermostat
- In areas that do not require conditioning
- Where there are dead spots or drafts (in corners or behind doors)
- Where appliances could radiate heat
- Do not set it next to or on hot appliances
- Do not put it in your pocket or hold in your hands for a long period of time.
- Body heat will distort the temperature reading.

## Getting to know your indoor remote sensor or zone control




- 1 LCD
- 2 Glow in the Dark Light Button\*
- 3 Temperature Setpoint Keys\*\*
- 4 Remote Name
- 5 Run and Clean Keys\*\*

### Wireless Range

Range between the remote and the master thermostat is approximately 100 feet with no obstructions and approximately 50 feet in standard residential metal, brick, and concrete construction.

**\*NOTE ABOUT THE LIGHT BUTTON:**  
This button is used to light up the display. DO NOT hold the light button down for longer than 3 seconds or you will enter the technician setup screens. If inadvertently enter the tech setup press and release the light button a second time to exit the tech screens.

**\*\*NOTE ABOUT SETPOINT, RUN, AND CLEAN KEYS:**  
These keys will only be shown if they have been turned on in Technician Setup menu.



**Setpoint Adjustment Keys**  
NOTE: The SHOW SET must be set to YES in tech setup menu before the setpoint keys will be shown in the display.

**Low Battery Indicator**  
Replace batteries when this indicator is shown.

**Remote Label**  
Each indoor remote sensor can be labeled. The label options can be found during tech setup.


**Run Key**  
RUN only shows if the remote sensor setpoint has been changed. Pressing RUN will cancel the temporary setpoint hold. Note: The SHOW SET must be set to YES in tech setup menu before the RUN key will be shown in the display.

2


## Mounting Options

### Wall Mount - Removable

- 1 Mount T-bracket on the wall.



- 2 Slide the Remote Sensor over the mounted T-bracket.




3


4

Desk or Counter Option

- 1 Slide the T-bracket up into the slot holders.




- 2 T-bracket will stop on the top of the slot holders.




Wall Mount - Permanent

- 1 Remove the remote from the subbase.



- 2 Mount subbase to the wall




5


Installing Batteries

Temporary Wall Mount or Table Placement

- 1 Use the finger tab on the back of the remote to remove the battery door.



- 2 Once you have removed the door from the back of the remote, insert 2 AA Alkaline batteries and replace the battery door.




7

6


Installing Batteries

Inserting Batteries for Permanent Wall Mount


- 1 Remove the remote from the subbase. It is held on the subbase by a plastic tab on the bottom of the remote sensor. Push in with a small flat head screwdriver to remove it from the subbase.



- 2 Once you have removed the remote from the subbase, insert 2 AA Alkaline batteries.



- 3 Attach the remote to the subbase by aligning the two top tabs and then close as shown.




8

Connecting to the Master Thermostat

Easy communication link set up.

(The remote sends temperature information every 5 minutes.)


1. The Thermostat Tech setting for the **Remote Sensor** must be set to **YES**. See the thermostat manual for instructions.
2. Navigate the Thermostat to the FINDING SENSORS technician setup step and then select the zone you wish to connect to that remote.
3. On the Remote Sensor hold the LIGHT button for 3 seconds to enter the tech setup screens.
4. In the 2nd tech setup step, choose the zone number selected on the Master Thermostat
5. While in the ZONE tech setup step on the remote, hold the light button down until the wireless icon flashes, approximately 3 seconds.




**NOTE:** you can only connect one **REMOTE** to each zone.

**EXAMPLE:** if you would like to connect two **REMOTES** to the **Thermostats**. Then connect the first one to **Zone 1** and the second one to **Zone 2**.


Example Step 3 and 5.



**Example Step 1.** Master Thermostat Remote Sensor set to **YES**. Then press **NEXT STEP**.



**Example Step 2.** The Thermostat Finding Sensor zone numbers must match the zone number on the **REMOTE**



**Example Step 6.** The Thermostat now displays the name and the ambient temperature of the **REMOTE**.

Technician Setup Menu

This remote sensor has a technician setup menu for easy installer configuration. To set up the remote for your particular application:

1. Press and hold the LIGHT button for 3 seconds. This 3 second delay is designed so that homeowners do not accidentally access the installer settings.
2. Configure the installer options as desired using the table below.
3. Use the  $\Delta$  key to move to the next tech setup screen. Use the  $\nabla$  key to make adjustments to the settings.

**NOTE:** Press and release the light button when you want to exit the tech setup screens.

Tech Setup Steps	LCD Will Show	Adjustment Options	Default
System Select		<b>THERMSTAT:</b> The remote is configured to a wireless thermostat. <b>ZONING:</b> The remote is configured to connect to wireless zoning system Master Thermostat.	THERMSTAT
Zone Selection		Zone 1, Zone 2, Zone 3, Zone 4 The Zone number on the remote and the Thermostat must match in order to establish a connection See previous page to connect.	ZONE 1
Remote Name		Remote 1, Remote 2, Remote 3, Remote 4, Bedroom 1, Bedroom 2, Bedroom 3, Bedroom 4, Kitchen, Living Room, Hall, Family Room, Dining Room, Office, Study, Den, Loft, Upstairs	REMOTE 1
Show Set		<b>N:</b> The remote is used as a sensor only and cannot change the current set point. <b>Y:</b> Enables the temperature adjustment keys allowing the user to temporarily override the thermostat set point with the remote.	OFF

Remote Sensing Technician Setup Menu

Remote Sensor Configuration

Tech Setup Steps	LCD Will Show	Adjustment Options	Default
Room Temperature Calibration		You can adjust the room temperature display to read + or - 4 degrees from the factory calibrated settings.	0
F° or C°		F for Fahrenheit C for Celsius	F
Low Temperature Setpoint		Use the $\nabla$ key to select the minimum cool setpoint.	44°F
High Temperature Setpoint Limit		Use the $\Delta$ key to select the maximum heat setpoint.	90°F

Sensor Only Mode

(SHOW SET tech screen set to N)

In sensor only mode (set to **N**) the remote will not allow you to change the set point. The current ambient temperature will be displayed and transmitted to the **Thermostat** every five minutes. The ambient temperature will be used for controlling when system average is selected and whenever it is given priority by the program in the **Thermostat**.

Adjustable Remote Mode

(SHOW SET tech screen set to Y)

In show set mode it will show the temperature setpoint arrows and the **CLEAN** key.

In this mode the **Remote** can be used to override the **Thermostats** current settings for 4 hours in addition to being used as temperature sensor.


OVERRIDE PROCEDURE:

Press the up or down arrows on the **Remote**. The current ambient temperature will be displayed. Adjust the temperature reading to the desired set point.


The **Thermostat** will display the zone that currently has control and the Temperature at the remote. The word **REMOTE** will be displayed on the **Thermostat** to show the remote has overridden the program. Allow up to 1 minute for the **Thermostat** to acknowledge an override from a **Remote**.

Pressing **Run Schedule** on the **Thermostat** will return the system to the programmed schedule.

The **Remote** will also show a **Run** key that can be pressed to return the **Thermostat** to the current programmed temperature, which cancels the hold.



Remote **SHOW SET** Tech Setup Screen



Remote **SHOW SET** Tech Setup Screen

**NOTE:** The **Remote** will show the Run key for 4 hours even if the Thermostat is put back in to normal operation or overridden by a 2nd remote. However, the last device changed will have priority.

**NOTE:** The last remote or master changed will have priority

**NOTE:** There is no permanent hold option for the remote but you can select a permanent hold from the **Thermostat**.

**NOTE:** Got to page 9 of this manual to see the instructions on how to connect this **REMOTE** to the **Thermostat**.


**NOTE:** Tech setup cannot be entered if the **REMOTE** is in temporary hold mode. Press the **RUN** key to exit temporary hold.

**Example of programming a priority for the SLEEP time period:**

In this example system we have 1 Thermostat on the main floor and 1 remote in the Master Bedroom on the 2nd floor. During the setup process the remote was named Bedroom 1. During WAKE, LEAVE and RETURN, the program should remain on system average. When on the SLEEP time period during programming, press NEXT ZONE until Bedroom 1 shows. During the SLEEP time period the other remotes in the house will be ignored and the system will be controlled only by the ambient temperature of the remote in the master bedroom. The WAKE, LEAVE and RETURN temperature will be controlled by the system average.

**New Features on the Thermostat After a remote is Connected**

**NEXT ZONE KEY**



**NEXT ZONE** key cycles through ambient temperatures for connected zones.


In this example, the name of the zone currently having priority is **SYSTEM AVERAGE**.

**System average** is the average of all connected sensors.

**Local** is the ambient temperature of the **Thermostat**.

The name of the **REMOTE** can be displayed. This shows it has priority.

**THERMOSTAT HOLD (PERMANENT)**




To put the thermostat into hold select system average or the zone you want to hold. Then use the arrows to adjust the setpoint. Then press the **HOLD** key.

**HOLD:** Indicates the Thermostat is in permanent **HOLD**. A permanent **HOLD** can be active for system average, local, or any **REMOTE**.

**Run Schedule:** Will cancel any holds and return the system to the program.


**SETPOINT NOT DISPLAYED**



Setpoint will only be displayed for the zone currently being used by the program or in hold. Press the **+** or **-** to show the setpoint for adjustment.

**TEMPORARY HOLD (4 HOURS)**

**REMOTE:** Indicates the **Master Thermostat** is in hold. The setpoint will now display the temporary override setpoint.



The name of the remote sensor will be displayed. In this example, it is **REMOTE 2**.


**Run Schedule:** Will cancel any holds and return the system to the program.

**Remote Sensing Specifications**

**Specifications**

The display range of temperature .....	32°F to 99°F (0°C to 37°C)
The control range of temperature.....	44°F to 90°F (7°C to 32°C)
Display Accuracy.....	± 1°F
Power source .....	Battery power from 2 AA Alkaline batteries
Operating ambient .....	32°F to +105°F (0°C to +41°C)
Operating humidity .....	90% non-condensing maximum
Dimensions of thermostat .....	2.75"W x 4.5"H x 1.375"D
Frequency.....	916 MHz
Sending Data.....	Every 5 minutes
Reading Temperature.....	Every 60 seconds

Our Wireless Zoning System contains selectable wireless communication. Each component has a jumper switch labeled FSK and ASK. Default Setting: FSK. All components must be set to the same position for wireless communication. This selectable communication option is available to you in case you have a device you are pairing with that only has the ASK option.



Connecting to the Master Thermostat

**Easy communication link set up:**

**STEP 1.** Remote Zone Thermostat: ZONING. Change Setting to "ZONING".

**STEP 2.** Remote Zone Thermostat: ZONE 2. Set Zone Number.

**STEP 3.** Master Thermostat: Set Zone Number.

**STEP 4.** Remote Zone Thermostat: Light button. Set At 74.

**STEP 5.** Master Thermostat: FOUND REMOTE 1.

- The Remote Zone Thermostat must be configured to "ZONING" in the first Tech Setup Step. See next page.
- In the next Tech Setup Step, you select the Zone Number that the Remote Zone Thermostat will be used to measure/control. (See page 7 for steps to enter Tech Setup.) This will be zones 2-5. (The Master Thermostat is always Zone 1.)
- Then set the Master Thermostat Zone number to match the Remote Zone Thermostat. See Installation Manual, Tech Setup Step "Zone Remote Thermostat".
- With both Remote Zone Thermostat and set to the same zone in their setup steps, press and hold the light button on the zone thermostat until the Wireless Icon flashes, approximately 3 seconds.
- The Master Thermostat should now show the temperature of the Remote Zone Thermostat, the Zone number it's configured for (Example 2) and it's name. If it hasn't been named yet, it will show

Technician Setup Menu

This zone thermostat has a technician setup menu for easy installer configuration. To set up the remote for your particular application:

- Press and hold the LIGHT button for 3 seconds. This 3 second delay is designed so that homeowners do not accidentally access the installer settings.
- Configure the installer options as desired using the table below.
- Use the  $\Delta$  key to move to the next tech setup screen. Use the  $\nabla$  key to make adjustments to the settings.

NOTE: Press and release the light button when you want to exit the tech setup screens.

Tech Setup Steps	LCD Will Show	Adjustment Options	Default
System Select	THERMSTAT	THERMSTAT: The remote is configured to a wireless thermostat. ZONING: The remote is configured to connect to wireless zoning system Master Thermostat.	THERMSTAT
Zone Selection	ZONE 1	THERMSTAT: Zone 1,2,3,4 ZONING: ZONE 2,3,4,5 The Master Thermostat is always ZONE 1.	ZONE 1
Remote Name	REMOTE 1	Remote 1, Remote 2, Remote 3, Remote 4, Bedroom 1, Bedroom 2, Bedroom 3, Bedroom 4, Kitchen, Living Room, Hall, Family Room, Dining Room, Office, Study, Den, Loft, Upstairs	REMOTE 1
Show Set	SHOW SET	ZONING: Enabling this feature will allow the zone remote to control the SYSTEM mode, FAN mode, and setpoint temperature of the zone. Disabling it will turn all control of that zone over to the master thermostat.	OFF

Zoning Technician Setup

Zoning Specifications

Tech Setup Steps	LCD Will Show	Adjustment Options	Default
Room Temperature Calibration	CALIBRATE	You can adjust the room temperature display to read + or - 4 degrees from the factory calibrated settings.	0
F° or C°	F FAHRENHIT	F for Fahrenheit C for Celsius	F
Low Temperature Setpoint	44 LOW LIMIT	Use the $\nabla$ key to select the minimum cool setpoint.	44°F
High Temperature Setpoint Limit	90 HIGH LIMIT	Use the $\Delta$ key to select the maximum heat setpoint.	90°F

Specifications

The display range of temperature ..... 32°F to 99°F (0°C to 37°C)  
 The control range of temperature..... 44°F to 90°F (7°C to 32°C)  
 Display Accuracy..... ± 1°F  
 Power source ..... Battery power from 2 AA Alkaline batteries  
 Operating ambient ..... 32°F to +105°F (0°C to +41°C)  
 Operating humidity ..... 90% non-condensing maximum  
 Dimensions of thermostat ..... 2.75"W x 4.5"H x 1.375"D  
 Frequency.....916 MHz  
 Reading Temperature.....Every 60 seconds