



## LAV & Toilet Riser Installation



### Installation

- The plain end of the riser should be cut clean and square. Make sure the tubing bottoms out in supply stop body to ensure a good seal. Use supplied plastic compression sleeve only.
- 3/8" OD plastic tubing and smaller the use of a plastic sleeve is required.
- Hand tighten ballcock nut - DO NOT OVERTIGHTEN
- 3/8" metal nuts - hand tighten plus 1-1/2" to 2-1/2" additional turns.
- When properly tightening the compression sleeve should not allow the tubing to be removed by hand.

### Warning

- Pipe dope, compounds and sealants should not be used for installation because they have been known to cause leakage.