

## Installation

Slip them on the pipe, push them into the joist bore, tack them in with a screw or two, and the expansion and contraction of the line is instantly silenced. The pipe is now sliding on plastic rails and not chattering across raw wood.

