

- Position the grip rail so the setscrews are to the bottom.
- Press the grip rail fully onto the studs. Then push downward on the grip rail so the narrow slots in the grip rail fit over the grooves in the studs. Use a 3/32" ball style hex wrench to securely tighten the grip rail setscrews. Make sure the grip rail is secure.
- Repeat for the other grip rail.

