



SharkBite Max Depth and Deburr Tool

Installation Instructions

1. Tool Identification:

- Note the two distinct sides of the tool: one for SharkBite First Generation fittings and the other for SharkBite Max fittings.

2. Preparation:

- Ensure your pipe is cut cleanly and squarely.

3. Deburring Process:

- Insert the pipe end into the deburring hole matching your pipe size.
- Rotate the tool around the pipe at least 10 times for effective deburring.

4. Depth Marking:

- Use the tool's depth gauge to mark the correct insertion depth on your pipe.
- Align the pipe with the size slot on the tool and mark at the edge.

5. Fitting Installation:

- Insert the pipe into the SharkBite fitting up to the depth mark.
- Ensure straight and complete insertion for a secure connection.

6. Testing and Safety:

- Test the system for leaks and proper function.
- Handle and store the tool with care.