

### Tools & Protection material Required

Scissors, or any cutters, protection gloves

### Preparation

Wearing the protection gloves, Opening the package by Scissors or any cutters

### Precaution

1. The tool is for the cable ties max with 9mm width (0.354" width)
2. Do not suggest this tool for the minimum, intermedium cable ties.

### Installation and Operating

1. Wear gloves
2. Enter the tail of the cable ties into the tool's mouth  
see picture 2

Remarks: the teeth of the ties to be downside

The entrance of the tool mouth is the non-pawl side

3. Hold and press the handle of the tool A and B to tension the cable ties  
see picture 3
4. Till the tie has been bundled tightly, then pull the handle C to cut the tie  
see picture 4
5. Installation finished

