

INSTRUCTION GUIDE

ROOF FLASHINGS



1 Make sure the roof is free of all debris and is ready for shingle installation.

2 Chamfer the pipe end prior to the flashing installation.

3 Install the shingles in rows starting from the bottom of the roof and work upwards to the peak. (Be sure to overlap the row below for good waterproofing qualities.)

4 Once you are near the pipe penetration, push the flashing down over the chamfered pipe end and position it flush against the felt paper layer and shingles.

5 Secure the flashing with roofing nails and make sure that all nails are concealed under the next few rows of shingles to keep the roofing system leak free.

6 Install the shingles in rows to the top of the roof.

7 Test the flashing by running water over it for 3 to 5 minutes.

