



INSTRUCTIONS FOR MOUNTING

NO. 12-780 LAVATORY*

1. MARK CENTER LINES FOR LOCATION OF LAVATORY IN SLAB OR COUNTER TOP.
2. CUT OUT TEMPLATE USING THE CENTER LINE ARROWS AS A GUIDE, TRACE LINE ON COUNTER TOP.
3. CUT OPENING IN COUNTER TOP CAREFULLY, FOLLOWING PENCIL LINE YOU TRACED.
4. MOUNT LAVATORY TO UNDERSIDE OF COUNTER TOP, LOCATING AS PER DIMENSIONAL DRAWING ON RIGHT. GERBER ANCHOR KIT #99-190 IS AVAILABLE TO SUPPORT THIS MOUNTING.
5. THE DIMENSIONAL DRAWING AT RIGHT INDICATES THAT THE FAUCET HOLES SHOULD BE DRILLED 2 1/2" BEHIND THE CUTOUT FOR THE LAVATORY, CHECK THE HOLE DIAMETERS AND SPREAD OF INTENDED FAUCET BEFORE DRILLING HOLES.

*NOTE: DUE TO SLIGHT DIMENSIONAL VARIATIONS WE RECOMMEND USING LAVATORY AS A TEMPLATE TO INSURE PROPER ALIGNMENT OF UNDER COUNTER INSTALLATION.

PN 0099803, REV. 5-2009
THIS TEMPLATE IS FOR 12-780 LAVATORY

