



## PEX Escutcheons

### INSTALLATION

- Slide the escutcheon over the exposed  $\frac{1}{2}$ " PEX tubing. Mark the proper tubing length. Cut the tubing. Slide the escutcheon back over the tubing and make the Flared PEX connection.

