

NY Thermal Inc.
Tel: (506) 657-6000
Toll Free: 1-800-688-2575
Fax: 1-506-432-1135
Web: www.nythermal.com
Email: info@nythermal.com

84921

Retaining Clip, Combi Block Inlet/Outlet (59200188)

Applicable Boiler Models

- Tx151C

Kit Contents

- 1 Retaining Clip

Tools Required

- ¼" Nut Driver

Replacement Instructions

- 1) Turn off power and gas to the boiler.
- 2) Drain boiler of water.
- 3) Remove clip by rotating counter clockwise until it snaps out of place.
- 4) Replace clip by fitting it into place, pushing, and then rotating clockwise until it "clicks" into place.

Note: Clip will only fit one way. (See figures on the right)

- 5) Refill boiler with water and purge excess air.

CAUTION

Air in Boiler - Ensure the boiler is completely filled with water to a minimum of 15psi, and that all the air is purged. Failure to do so could result in a boiler malfunction causing property damage.

