INSTALLATION INSTRUCTIONS

The APOLLO RVW16 Pressure Relief Valve is to be installed for system over protection. This valve is not intended for steam service. CAUTION - During operation, this valve may discharge large amounts of high pressure, hot liquid. To reduce the potential for bodily injury and property damage

- 1. A discharge line must be installed that is connected from the valve outlet to a safe point of discharge
- 2. No intervening valve
- 3. Allows complete drainage of the valve and discharge line
- 4. Is independently supported and securely anchored to avoid applied stress on the valve
- 5. Is as short and straight as possible
- 6. Terminates freely to atmosphere where any discharge will be clearly visible and is at no risk of freezing
- 7. Is of a pipe size equal or greater than the valve outlet.

<u>WARNING!</u> This Product contains chemicals known to the state of California to cause cancer and birth defects or other reproductive harm. (California law requires that this warning be given to the customers in the State of California.)

For more information visit www.apollovalves.com.

This product meets the requirements of the EPA Safe Drinking Water Act.