

Installation

Tools Required: Hacksaw

1. Turn off water supply to sink. Place bucket under trap.
2. Loosen nuts (1) & (2) with washers and remove old tailpiece (A). Keep nuts if in good condition.
3. Measure distance (D) as illustrated. Cut to length with hacksaw if necessary.
4. Position nut (1) with washer on flanged tailpiece (A) as shown. Thread nut to strainer (B).
5. Position nut (2) with washer on tailpiece and connect to drain tube or trap (C).
6. Tighten all nuts.
7. Turn on water supply to sink. Check connections for leaks.

