



LYNN MANUFACTURING, INC.
15 MARION STREET
LYNN, MASSACHUSETTS 01905
TEL: (781) 593-2561 - FAX: (781) 596-0430

Installation Instructions

Instant-Glo

REPLACEMENT CHAMBER FOR
MILLER GUN FURNACE
FIRING RATE .50 TO .60 G.P.H.

1. At all times, handle chamber with care. It is designed as a one piece assembly and should not be cut into segments for installation.
2. Disconnect oil and electrical connections.
3. Remove the three hexagon nuts holding burner and remove burner.
4. Remove sheet metal screws holding pouch access panel in place.
5. Loosen nuts holding the pouch assembly in position and remove pouch assembly.
6. Clean inside of heat exchanger.
7. To install new chamber, carefully tilt top of chamber in first and raise a few inches. Tilt bottom in and position chamber properly.
8. Reassemble.

NOTE:

We do not recommend the use of thermal bomb type furnace cleaners with any of our Kaowool Products. In addition, we do not recommend any liquid fuel oil additives, cleaners, or efficiency boosting chemicals that can attack and cause deterioration of ceramic fiber products. We do not recommend the use of the above with any of our Kaowool products.

WARRANTY:

This product is warranted to be free of manufacturing defects. Lynn Manufacturing Inc. will replace it at no charge. Replacement is the only obligation of Lynn Manufacturing Inc. and Lynn Manufacturing Inc. will not be responsible for any loss or damage resulting from the sale or use of this product, even if loss or damage is caused by the negligence or fault of Lynn Manufacturing Inc.