Westwood REPLACEMENT ZONE VALVE MOTOR

FOR MOTOR DRIVEN OPEN, SPRING RETURN CLOSE VALVES (IE. ERIE, FLARE, HONEYWELL, SUPERIOR)

INSTALLS WITHOUT REMOVING VALVE FROM PIPING USING EASY TO INSTALL EXTENDED BRASS SCREWS



