



H2Okinetic Wall Mount
Handshower
55411
Single Setting





H2Okinetic Handshower
with Slide Bar
51205
Single Setting



H2Okinetic Wall Mount
Handshower
55421
Single Setting



H2Okinetic Handshower
with Slide Bar
51552
4 Setting
Recommended for use with Tesla™
See collection on page 62



H2Okinetic Wall Mount
Handshower
55525
4 Setting
Recommended for use with Tesla
See collection on page 62






ActivTouch® Handshower
with Slide Bar
51504
9 Setting
Multiple configurations available



ActivTouch Shower Mount
Handshower
54424-PK
9 Setting
Multiple configurations and
WaterSense® labeled models available



Palm® Shower Mount
Handshower
54456-PK
4 Setting
Multiple configurations available



Premium Handshower
with Slide Bar
51708
7 Setting
Multiple configurations available



5 Setting



Premium Handshower
with Slide Bar
51508
5 Setting
Multiple configurations available



Premium Handshower
with Slide Bar
51505-DS
5 Setting
Multiple configurations available

