



ADD-ON FAUCET SPOUTS
See Page 101

ITEM #	PART #	DESCRIPTION
1	77189	2-3/4" Hooded Lever Blade Handle, Screw, Red & Blue Index
2	060022A	* Handle Screws, Index Kit (includes handle screws, red & blue index washers)
	060442A	No. 3 Scrulox 8 Screwdriver for above
	060145A	* Handle Screws for 77189 Handle above
	060148A	* Red & Blue Index Washer Kit
	060441A	No. 3 Scrulox 8 Driver Bit
	060440A	No. 3 Square Driver Bit
3	77260	RH CP Brass Tuf-Teck Structure & Renewable Seat (for hot water side & for add-on faucet)
	77261	LH CP Brass Tuf-Teck Structure & Renewable Seat (for cold water side)
4	060021A	* Structure Repair Kit (includes seat washers, screws, stem & capnut "O" rings, capnut fibre washers, renewable seats)
	060139A	* Seat Washer Package
	060140A	* Stem "O" Ring Package
	060142A	* Structure Capnut "O" Ring Package
	060144A	* Renewable Seat Package
5	060026A	* Riser Pipe Repair Kit (includes retaining rings, "O" rings, swivel & rigid collars, and spout nut)
	060143A	* Spout "O" Ring Kit
	060244A	* Rigid Collar Kit
	060245A	* Retaining Ring Kit
6	060386A	Rigid/Swivel Adaptor and Fibre Washer
7	060469A	Fibre Washer – 12 per
8	060471A	Pair of 10" Offset Shanks & Washers
9	060466A	Wall Flange & Set Screw
10	060465A	Shank Rubber Washer Kit – 12 per
11	060472A	Integral Check Structure Complete
12	060473A	Thin Wall Installation Kit
13	17023	Riser Pipe Adaptor
14	17034	Swing Spout Adaptor
15	060494A	Spray Head Hook & Screw
16	55P1000	Wall Bracket Complete
17	060495A	Spring Retainer
18	060496A	Pre-Rinse Spring Only
19	060497A	Hose Assembly & Insulated Grip
	060498A	Hold Open Ring Only
21	060499A	Spray Head & Hold Open Ring
	060503A	Water/Energy Saver Spray Faceplate
	060290A	Spray Valve Repair Kit – includes cartridge, spray face, screw, bumper, plastic spacer – 1 of each
	060291A	Spray Valve Cartridge

* For Package Quantities check the parts section of the latest Delta Commercial Faucet Price List