

# SUPERFLOW SERVICE PART KITS



P-911D-BK



P-911D



Parts Service kits are an easy and cost-effective way to maintain and service IBC boilers.

## **P-911D**

**SUPERFLOW –1 Parts Service Kit Orange**  
custom made foam case containing  
individually labeled parts. *See reverse.*

## **P-911D-BK**

**SUPERFLOW –1 Parts Service Kit**  
Black tool box containing boxed parts kits.

- Kits contains original, high-quality IBC spare parts in a convenient compact case.
- Each service kit is tailored to the requirements of the SUPERFLOW product line.
- Kits contains all the major parts needed for servicing including: Fan, Controller, Gas Valve, Ignitor, Sensors, gaskets etc.
- Convenience in one package without the need for multiple parts orders.
- Reduces inventory costs
- Reduces service times and down time.

**SAVE MONEY**  
**SAVE TIME**

**IBC®**

| Part#           | Qty | Description                                   |
|-----------------|-----|-----------------------------------------------|
| <b>P-081354</b> |     | <b>Heat Exchanger Service Kit</b>             |
| 255-073         | 1   | Heat exchanger gasket                         |
| <b>P-081784</b> |     | <b>DHW Temperature Sensor (15mm)</b>          |
| 240-070         | 1   | DHW temperature sensor (15mm)                 |
| <b>P-081074</b> |     | <b>Manual Air Vent</b>                        |
| 180-227         | 1   | Manual air vent                               |
| <b>P-081134</b> |     | <b>Flue Temperature Sensor</b>                |
| 180-205         | 1   | Flue temperature sensor                       |
| 150-314         | 1   | Flue temperature sensor knob                  |
| 150-396         | 1   | Flue temperature sensor gasket                |
| <b>P-081174</b> |     | <b>Fan</b>                                    |
| 240-120         | 1   | Fan                                           |
| 250-627         | 1   | Fan gasket                                    |
| <b>P-081224</b> |     | <b>Boiler Pump</b>                            |
| 180-130         | 1   | Boiler pump                                   |
| 250-634         | 2   | Boiler pump gasket                            |
| <b>P-081234</b> |     | <b>Gas Valve</b>                              |
| 180-215         | 1   | Gas valve                                     |
| 150-175         | 1   | Orifice O-ring 19x2                           |
| 150-206         | 1   | Gas valve inlet gasket                        |
| <b>P-081264</b> |     | <b>DHW Flow Sensor</b>                        |
| 180-241         | 1   | DHW flow sensor (turbine)                     |
| 240-177         | 1   | DHW flow sensor insert                        |
| 240-122         | 1   | DHW flow sensor (clip on)                     |
| 150-208         | 2   | DHW gasket 18.5x13x2                          |
| <b>P-081294</b> |     | <b>Heat Exchanger Temperature Sensor</b>      |
| 180-206         | 1   | Heat exchanger temperature sensor             |
| 150-236         | 1   | Heat exchanger temperature sensor bolt        |
| 150-237         | 1   | Heat exchanger temperature sensor washer      |
| <b>P-081314</b> |     | <b>Boiler Water Pressure Sensor</b>           |
| 180-221         | 1   | Boiler water pressure sensor                  |
| <b>P-081324</b> |     | <b>DHW Temperature Sensor</b>                 |
| 240-117         | 1   | DHW temperature sensor (18mm)                 |
| <b>P-081334</b> | 1   | <b>Controller</b>                             |
| <b>P-081454</b> |     | <b>Heat Exchanger Service Kit</b>             |
| 250-807         | 1   | Heat exchanger gasket                         |
| <b>P-081464</b> |     | <b>DHW Bypass Valve / Flow Sensor Turbine</b> |
| 240-121         | 1   | Bypass valve / flow sensor turbine            |
| 150-366         | 1   | Bypass valve / flow sensor turbine O-ring     |
| 255-032         | 2   | Bypass pipe gasket                            |
| 150-368         | 1   | HX fitting o-ring 15.0x2.0                    |
| 150-248         | 1   | HX fitting o-ring 19.3x2.4                    |
| 150-365         | 1   | HX fitting nut spring clamp 15mm              |

| Part#                   | Qty | Description                                   |
|-------------------------|-----|-----------------------------------------------|
| <b>P-081574</b>         |     | <b>Ignition Control Kit</b>                   |
| 209327                  | 1   | Ignitor                                       |
| 221354                  | 1   | Ignitor cable                                 |
| 250-622                 | 1   | Ignitor gasket                                |
| 150-235                 | 2   | Ignitor screw                                 |
| 180-202                 | 1   | Ignition module                               |
| 319047                  | 2   | Ignitor screw thread insert                   |
| <b>P-081694</b>         |     | <b>Supply Temperature Sensor</b>              |
| 240-178                 | 1   | Supply temperature sensor (22mm)              |
| <b>P-081804</b>         |     | <b>Cabinet Temperature Sensor</b>             |
| 230004                  | 2   | Cabinet Temperature Sensor                    |
| <b>P-081814</b>         |     | <b>DHW Strainer Assembly</b>                  |
| 842974                  | 1   | DHW strainer assembly                         |
| <b>P-082444</b>         |     | <b>Combustion Gasket Set</b>                  |
| 150-245                 | 1   | Gas pipe to venturi O-ring 15x2               |
| 150-206                 | 1   | Gas valve inlet gasket                        |
| 150-175                 | 1   | Orifice O-ring 19x2                           |
| 150-343                 | 4   | Burner screw O-ring 6x1.5                     |
| 250-627                 | 1   | Fan gasket                                    |
| <b>P-082454</b>         |     | <b>Hydronic Gasket Set</b>                    |
| 180-238                 | 1   | HX fitting O-ring 21.9x2.62                   |
| 150-248                 | 6   | Field fitting O-ring 19.3 x 2.4               |
| 620174                  | 2   | Field fitting O-ring 30.3x2.4                 |
| 150-392                 | 2   | HX fitting O-ring 13x2                        |
| 150-208                 | 4   | DHW gasket 18.5x13x2                          |
| 150-366                 | 1   | Bypass valve / flow sensor turbine O-ring     |
| 250-634                 | 2   | Boiler pump gasket                            |
| 842614                  | 1   | DHW strainer O-ring 15.8x2.4                  |
| 250-635                 | 1   | HX supply pipe gasket 24x20x1.5               |
| 150-368                 | 2   | HX fitting O-ring 15.0x2.0                    |
| 255-032                 | 2   | Bypass pipe gasket                            |
| <b>P-082424</b>         |     | <b>DHW Bypass Valve / Flow Sensor Turbine</b> |
| 620044                  | 1   | Bypass valve / flow sensor turbine O-ring     |
| 620034                  | 3   | HX fitting o-ring 19.3x2.4                    |
| <b>Individual Parts</b> |     |                                               |
| 240-023                 | 5   | Control module 5A fuse                        |
| 150-244A1               | 1   | Venturi locking clip                          |
| 150-344                 | 4   | Burner screws                                 |
| 150-241                 | 1   | Burner ground spring                          |
| 250-646                 | 1   | Burner gasket                                 |
| 250-808                 | 1   | Burner gasket                                 |
| 180-184                 | 1   | Backflow insert flapper                       |
| 150-312                 | 1   | Flue pipe/HX gasket                           |
| 150-313                 | 1   | Flue pipe outlet gasket                       |

**IBC Technologies USA, Inc.**

121 Walter A Gaines Way, Lawnside, NJ 08045

[www.ibcboiler.com](http://www.ibcboiler.com)
[sales@ibcboiler.com](mailto:sales@ibcboiler.com)

856-887-0544 / 1-844-HEAT IBC