



AIR ACTIVATED SWITCH BUTTON WITH CONTROL BOX FOR WASTE DISPOSAL

ROHL Kitchen Accessories

AS450

FEATURES

- Remote on/off air switch button
- Transmitter button with escutcheon, base and fastening nut included
- 1 1/4" cutout, 2" max. installation depth on deck or wall
- Escutcheon and button made of brass
- Control box comes with mounting hardware
- 60" flexible tubing included
- Button and escutcheon adhered to base
- Matches ROHL finishes
- Plug-in installation of control box

COLORS/FINISHES

- Polished Chrome
- Polished Nickel
- Satin Nickel
- Tuscan Brass
- English Bronze
- Inca Brass

WARRANTY

- Two years on manufacturer defects
- No warranty on Tuscan Brass finish

