

ITEM	PART NO.	DESCRIPTION
10	77933S	Blower wheel
11	98629S	Motor PSC 1/15HP
	98022S	Motor PSC 1/6HP (Can be used on gas same as oil)
12	98282AS	Hardware kit for EZGAS/EZGAS PRO
13	98498S	Hinged cover plate for Ignitor
14	4180002S1	Ignitor for EZGAS & EZGAS PRO
15	602002FR363S	Primary Control Microprocessor Flame Rod
	98572AS	Ignitor electrode/flame rod assembly 10"
16	98572BS	Ignitor electrode/flame rod assembly 12"
	98572CS	Ignitor electrode/flame rod assembly 14"
	98572DS	Ignitor electrode/flame rod assembly 16"
	98572ES	Ignitor electrode/flame rod assembly 18"
17	50822S	Transformer EZGAS PRO
18	GPROT0TES	EZGAS PRO Burner Service kit Tote for PRO burners (not shown)
	EZGAST0TES	EZGAS Burner Service kit Tote for 120V burners (not shown)
19	99017S	Test Kit – Includes FR Test Jack & Spark Tester (not shown)
20	50873AS	Electrode/ Flame Rod for 10" EZGAS
	50873BS	Electrode/ Flame Rod for 12" EZGAS
	50873CS	Electrode/ Flame Rod for 14" EZGAS
	50873DS	Electrode/ Flame Rod for 16" EZGAS
	50873ES	Electrode/ Flame Rod for 18" EZGAS
21	EZGFRWIRES	EZGas Flame Rod Wire (not shown)

NOTE: EZGas Service Kit Totes – see page 64

ITEM	PART NO.	DESCRIPTION
1	99392AKITS	10" Air Tube Kit, A Diffuser w/ Field Drilled Orifice
	99392BKITS	10" Air Tube Kit, B Diffuser w/ Field Drilled Orifice
	99392CKITS	10" Air Tube Kit, 9-Slot Diffuser w/ Field Drilled Orifice
	99392DKITS	12" Air Tube Kit, A Diffuser w/ Field Drilled Orifice
	99392EKITS	12" Air Tube Kit, B Diffuser w/ Field Drilled Orifice
	99392FKITS	12" Air Tube Kit, 9-Slot Diffuser w/ Field Drilled Orifice
	99392GKITS	14" Air Tube Kit, A Diffuser w/ Field Drilled Orifice
	99392HKITS	14" Air Tube Kit, B Diffuser w/ Field Drilled Orifice
	99392NKITS	14" Air Tube Kit, 9-Slot Diffuser w/ Field Drilled Orifice
	99392SKITS	16" Air Tube Kit, A Diffuser w/ Field Drilled Orifice
2	50833AS	Flange/Gasket Kit
	50821AS	Gasket Kit – Includes 50821 & GSKTKIT1 (not shown)
3	50808KITS	Full Firing Rate Kit – A, B & 9S Diffuser + 2 Airbands
	98522S	Air Flow Switch 120 Volt
4	50806S	Air Flow Switch 24 Volt
	98554S	Blower sensing lines kit – Only used on EZGAS 120V version (not shown)
5	50824S	Gas valve 24 volt
	98523S	Gas valve 120 volt
6	50819AS	Gas valve power harness (EZGas Pro only)
	9938440XX	Field drilled orifice

ITEM	PART NO.	DESCRIPTION
1	98514AAKITS	8" Air Tube w/ A Diffuser & Gas Can
	98514ABKITS	8" Air Tube w/ B Diffuser & Gas Can
	98514BAKITS	10" Air Tube w/ A Diffuser & Gas Can
	98514BBKITS	10" Air Tube w/ B Diffuser & Gas Can
	98514CAKITS	12" Air Tube w/ A Diffuser & Gas Can
	98514CBKITS	12" Air Tube w/ B Diffuser & Gas Can
	98514DAKITS	14" Air Tube w/ A Diffuser & Gas Can
	98514DBKITS	14" Air Tube w/ B Diffuser & Gas Can
2	98514EAKITS	16" Air Tube w/ A Diffuser & Gas Can
	98514EBKITS	16" Air Tube w/ B Diffuser & Gas Can
2	59642BLUS	Flange/Gasket kit for 201GAS
3	40287S	Gasket for Flange only
4	98542S	Air Band 2 Slot for 201Gas and 202Gas
	47001S	Air Band 4 Slot for 201Gas, 202Gas
5	98521KITS	Airflow switch and mounting plate assembly for 201Gas
6	98557S	Blower sensing line kit inlet and outlet
7	98523S	Gas valve VP4305M-4540 for EZGAS and 201Gas
8	9938440XX	Field drilled orifice for EZGASPRO, EZGAS & 201GAS
9	28563S	Blower wheel (used on 201/301 Oil and Gas)

ITEM	PART NO.	DESCRIPTION
10	98611S	Motor 1/6HP 120V 60Hz, 48N Frame
	98630S	Motor 1/4HP 120V 60Hz, 48N Frame (used on oil 201/301)
11	98534S	Hinged cover plate for Ignitor
12	4180002S2	Ignitor for 201GAS
13	6020002FR363S	Primary Control Microprocessor Flame Rod
14	98433AS	Ignitor electrode/flame rod 8"
	98433BS	Ignitor electrode/flame rod 10"
	98433CS	Ignitor electrode/flame rod 12"
	98433DS	Ignitor electrode/flame rod 14"
	98433ES	Ignitor electrode/flame rod 16"
15	98540AS	Ignitor electrode/flame rod assembly 8"
	98540BS	Ignitor electrode/flame rod assembly 10"
	98540CS	Ignitor electrode/flame rod assembly 12"
	98540DS	Ignitor electrode/flame rod assembly 14"
	98540ES	Ignitor electrode/flame rod assembly 16"
16	59444BLUS	Optional forced draft flange
17	20GFRWIRES	201GAS Flame Rod Wire (not shown)

ITEM	PART NO.	DESCRIPTION	702Gas	702G/O
1	73007S	Orifice nipple assembly Natural Gas	•	•
	73007AS	Orifice nipple assembly Propane Gas	•	•
2	98523S	Pilot Gas valve 120 volt	•	•
3	99455S	Manual Gas Shutoff 3/4" NPT	•	•
	99225S	Manual Gas Shutoff 1" NPT	•	•
	99245S	Manual Gas Shutoff 1-1/4" NPT	•	•
	99246S	Manual Gas Shutoff 1-1/2" NPT	•	•
	99926S	Manual Gas Shutoff 2" NPT	•	•
4	99235S	High gas pressure switch	•	•
5	99234S	Low Gas pressure switch	•	•
6	99227S	Primary Gas Valve, Honeywell 48A 2169 1" NPT w/ bleed restrictor	•	•
	99434S	Primary Gas Valve, Honeywell 48A 2177 1-1/4" NPT w/ bleed restrictor	•	•
	99434AS	Primary Gas Valve, Honeywell V48A 2185 1-1/2" NPT w/ bleed restrictor	•	•
	99434BS	Primary Gas Valve, Honeywell 48A 2243 2" NPT w/ bleed restrictor		

ITEM	PART NO.	DESCRIPTION	702Gas	702G/O
7	99229S	Secondary Gas Valve Honeywell V4295A 1031 – 1" NPT	•	•
	99435S	Secondary Gas Valve Honeywell V4295A 1049 – 1-1/4" NPT	•	•
	99435AS	Secondary Gas Valve Honeywell V4295A 1056 – 1-1/2" NPT	•	•
	99435BS	Secondary Gas Valve Honeywell V4295A 1064 – 2" NPT	•	•
8	99233S	Gas Pressure Regulator 1" NPT Maxitrol RV-61	•	•
	99432S	Gas Pressure Regulator 1-1/4" NPT Maxitrol RV-81	•	•
	99432AS	Gas Pressure Regulator 1-1/2" NPT Maxitrol RV-81	•	•
	99432BS	Gas Pressure Regulator 2" NPT Maxitrol RV-91	•	•
9	99533S	Butterfly valve and crank arm – Eclipse 4BV-A, 1" NPT	•	•