



AIR ACTIVATED SWITCH BUTTON ONLY FOR WASTE DISPOSAL

AS425

FEATURES

- Remote on/off air switch button for activating continuous feed waste disposals
- Transmitter button with escutcheon, base and fastening nut included
- 1 1/4" cutout, 1 3/4" max. installation depth on deck or wall
- Escutcheon and button made of brass
- Does not come with control box, button only
- Button and escutcheon adhered to base

COLORS/FINISHES

- Polished Chrome
- Polished Nickel
- Satin Nickel
- English Bronze
- English Gold
- Satin English Gold
- Unlacquered Brass*

WARRANTY

- 2-year Limited Warranty
- * No Warranty

