600 LUMEN RECHARGEABLE TASK LIGHT / HEAD LAMP

(REFLECTIVE HEAD STRAP INCLUDED)

OPERATING INSTRUCTIONS

Press button 1x to activate HIGH MODE.
Press button 2x to activate LOW MODE.
Press again to turn OFF.
(Note: Leave any mode ON for 5 seconds or longer and your next press of the button turns light OFF)

TURBO INSTRUCTIONS

Press and hold button for 1 seconds from any mode.
Press again to turn OFF.

STROBE INSTRUCTIONS

Double-press the button from any mode.
Press again to turn OFF.

USING THE HEAD STRAP

The dual-position head strap light holder allows you to either set the light vertically or horizontally based on user preference.

This position allows for left to right rotation

This position allows for top to bottom rotation

USING THE MAGCABLE

Connect the MAGCABLE to a USB power source. Place light on the MAGCABLE charging dock. Charging indicator light will shine RED while charging, light will turn BLUE when fully charged.

Charging may take up to 2 hours based on battery status.



TURBO MODE 600 LUMENS

RUN TIME: 40 SECONDS

BEAM DISTANCE: 90 METERS

HIGH MODE 240 LUMENS

RUN TIME: 2 HOURS

BEAM DISTANCE: 56 METERS

LOW MODE 60 LUMENS

RUN TIME: 4.5 HOURS

BEAM DISTANCE: 28 METERS

STROBE MODE 600 LUMENS

RUN TIME: 2 HOURS

BEAM DISTANCE: 90 METERS

WARNING

AVOID EYE INJURY • Do not shine directly into beam or shine it directly into anyone's face. Doing so for more than a few seconds could cause retinal damage. Do not allow children to use LED lights or lasers under the supervision of an adult.

QUALITY GUARANTEE

This product is guaranteed against ■ defects in workmanship and material for the original owner for one year from date of purchase. Contact the Customer Service Department at www.nebotools.com or call 1-800-Nebo-Tools (1-800-632-6665) to request a Return Merchandise Authorization (RMA) number. Return the product with the RMA number and proof of purchase. Damaging, abuse or extreme use will void the warranty. Do not return batteries or chargers. Warranty does not include the return or replacement of the battery, unless the battery is defective within the first year of the warranty. Warranty does not include damage or loss in transit, or incidental or consequential ■ damages. ■ Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For warranty registration or to see other great NEBO® products visit:

www.nebotools.com

All copyrighted and copyrightable materials, including, without limitation, the logos, designs, text, graphics, pictures, copywriting and the selection and arrangement ("Materials") thereof are ALL RIGHTS RESERVED Copyright © 2019 Nebo Sports Group