



## HTOVLAPR Cane Touch Apron for OVL II™ Series

### GENERAL

The cane touch apron is an optional accessory designed to bring the bottom of bi-level units into line with each other to give a sense of symmetry, and to satisfy customer preference. For use on all Halsey Taylor OVL Series units. When installed properly all OVL units meet ADA requirements without the cane apron. Standard finish is gray ABS. Overall Dimensions: 5 1/4" W x 6" H x 10" D.

Note: Floor to underside measurements of cane apron equals 27" when mounted correctly.

### KIT CONSISTS OF:

- Gray ABS Cane Apron
- Installation Instructions

Use part #HTOVLAPR when ordering.

JOB NAME: _____ _____ _____
ENGINEER/CONTRACTOR NAME: _____
APPROVAL: _____
DATE: _____

## Cane Touch Apron



HTOVLAPR Cane Apron shown installed on  
Halsey Taylor Model OVL-II™SER-Q

# HTOVLAPR Cane Touch Apron for OVL-II™ Series

(CONTINUED)

## INSTALLATION INSTRUCTIONS FOR HTOVLAPR CANE APRON KIT

*Following example is for OVL-II™S Fountain.*

### INSTALLATION PROCEDURE:

- 1) Remove 5 screws and bottom cover plate.
- 2) Attach item 1 cane apron with four screws previously removed.
- 3) Bottom cover and remaining screw can be discarded.

