








## FAQs: Super Seal™ Sealant Advanced - Total - DRY R™

### 1. Are Super Seal™ Sealant Advanced and Super Seal™ Sealant Total compatible with all oils and refrigerants including R410a?

Yes, Super Seal is packaged in a vacuum and uses the system's refrigerant to charge the can and propel the sealant into the system. Use as per application guidelines below:

SIZE SYSTEM	PRODUCT APPLICATION	Super Seal™ Sealant Advanced	Super Seal™ Sealant Total
SMALL SYSTEMS up to 1.5 tons/5 kW	1 can of Advanced or Total	947KIT  - Removes 20 drops of water	971KIT  - Removes 20 drops of water - Plus, UV dye
MEDIUM SYSTEMS 1.5-5 tons/5-17 kW	1 can of Advanced or Total	944KIT  - Removes 20 drops of water	972KIT  - Removes 20 drops of water - Plus, UV dye
*LARGE SYSTEMS 5+ tons/17+ kW	*1 can of Advanced or *2 cans of Total	948KIT  - Removes 20 drops of water	972KIT  - Removes 20 drops of water - Plus, UV dye
*For systems 25+ tons/88+ kW visit <a href="http://www.diversitech.com">www.diversitech.com</a> or call 866.548.3644 for technical support.			

### 2. What size hole and pressures will Super Seal™ Sealant repair?

For optimum success, a system should not be leaking more than 15% of its total refrigerant charge over a 4-week period. Super Seal™ Sealant has been specifically designed to seal micro pores, 300 microns and smaller, characterized as 'champagne leaks', typically seasonal leaks. The seal will withstand 800 PSI as well as low pressure vacuum testing used in triple evacuation procedures. Super Seal™ Sealant will only temporarily seal cracks that are subjected to thermal expansion and contraction movement.

### 3. When should Super Seal™ Sealant be used?

Super Seal™ Sealant should be used when conventional leak detection methods are unsuccessful and all attempts to find and fix a leak have been exhausted. Use in compliance with the Montreal protocol and regional or federal laws for handling of refrigerant.

6650 Sugarloaf Parkway • Suite 100 • Duluth, GA 30097 • Tel: (678) 542-3600 • Fax: (678) 542-3702

[www.diversitech.com](http://www.diversitech.com)



**4. What happens if the can does not empty during installation?**

In this event, the contractor may either run through the 7 steps on the back of the can label again, or leave the system running, detach the can and hose from the system, attach the can and hose to a refrigerant cylinder and recharge the can to pressurize. With the system still running, reattach the newly pressurized can and hose to the low side service port and the product will empty.

**5. How does Super Seal Sealant work?**

Super Seal™ Sealant is a light, low viscosity, particle and polymer free liquid. The sealant is injected as a mist directly into the refrigerant stream through our patented misting orifice. As it travels with the refrigerant and oil throughout the system, the sealant exits the leak point and reacts with moisture in the atmosphere to form a low tensile crystalline structure creating a permanent seal.

**6. What happens if moisture is present in the system?**

All Super Seal™ Sealants contain Dry R™ in their formula adding an extra level of protection beyond what competitive sealants can offer. The active ingredient in Dry R™ reacts with water to eliminate 20 drops of moisture from inside the system. Systems with higher levels of moisture should have the liquid line drier replaced prior to installing Super Seal™ Sealant. DiversiTech® recommends that technicians always adhere to ARI recommended levels of moisture for HVAC/R systems.

**7. Will Super Seal™ Sealant clog the valve core when injecting product into the system?**

No, when the sealant is injected into the system, it has already been combined with the refrigerant charge which acts as a solvent, cleaning the valve core as it passes through.

**8. Will Super Seal™ Sealant harm the compressor or any other components in the system?**

No, the sealant is completely compatible with the electrical windings of the compressor motor. It will not interfere with compressor valves or form wax in capillary tubes, orifices, or thermostatic expansion valves, and does not impede the lubricity of the system oil in any way.

**9. What happens to Super Seal™ Sealant while it is in the system?**

The chemical formulation of Super Seal™ Sealant remains in a stable state while it travels within the refrigerant and oil. Only when the sealant exits at a leak point and contacts moisture in the air is when it begins to work and form a permanent seal.

**10. How long will Super Seal™ Sealant remain in the system?**

Super Seal™ Sealant will remain active up to 10 years in a closed system. If refrigerant charge is removed, Super Seal™ Sealant will be recovered with the refrigerant as well.

**11. What happens if a line bursts on a system containing Super Seal™ Sealant?**

Super Seal™ Sealant will exit with the refrigerant and no longer be present in the system. No extra precautions are required. Follow standard practices when making repairs.

**12. What happens to Super Seal™ Sealant if it is necessary to reclaim the refrigerant?**

Super Seal™ Sealant is removed with the refrigerant through the recovery process.