

PA-010 Tank Tray Installation Instructions



Model PA-010 Tray for Roth DWT 400L & 620L and Granby/Vilco Model 150 GSS

Note: Model PA-010 tray is designed to accommodate the ROTH DWT 400L & 620L tanks and the Granby/Vilco cylindrical model 150 GSS. In all cases the tank must be located indoors and must be lifted and placed inside tray.

Steps

1. Sweep area where new tank is being installed. The area must be clean to insure no rocks or debris remains on the floor surface.
2. Check the tray for damage prior to placing on the floor.
3. Position the PA-010 containment tray close to the final desired install location.
4. Install kits are not required for these tank installations.
5. Lift the tank and install tank in tray. Center the tank in tray and/or to desired location.
6. Slowly pull on tray lip from each end to slide, move and position tank & tray in final install position.
7. Install piping connections and tighten fittings.
8. Prior to filling tank, check and adjust the tank in the tray. In some cases the tank moves or shifts when tightening the fill and vent pipe fittings.
9. For leak monitoring, choose one of three Oil Yeller leak detection alarms.
10. Install filter over tank or at the burner using a PA-008 or PA-005 L-shape tray.