### **INSTALLATION INSTRUCTIONS**

P24490-CR, P24490-LV, P24491-CR, P24491-LV, P24492-CR, P24492-LV, P24700, P24705, P24706, P24736, P24800

## **INSTALLATION INSTRUCTIONS**

#### THANK YOU FOR CHOOSING KALLISTA

We appreciate your commitment to KALLISTA quality products. Please take a moment to review this manual before you install your KALLISTA product. If you encounter any installation or performance problems, please do not hesitate to contact us at the phone number listed at the bottom of the page.

#### **IMPORTANT INFORMATION**

- Before installation, unpack the new faucet and inspect it for damage. Return the faucet to its protective carton until you are ready to install it.
- □ Observe all local plumbing and building codes.
- □ Shut off the water supply.
- □ Inspect the drain and supply tubing. Replace if necessary.
- □ If possible, assemble the faucet to the lavatory before installing the lavatory.
- □ The appearance of your product may differ from what is shown in these instructions, however, the installation procedure is the same.
- KALLISTA reserves the right to make revisions in the design of products without notice, as specified in the Price Book.

#### **TOOLS AND MATERIALS**



Adjustable Wrench



Phillips Screwdriver



Supply Hoses



Thread Sealant



Plumbers Putty



100% Silicone Sealant

## **INSTALLATION INSTRUCTIONS**



#### Install the Spout

- □ Remove the tee assembly, nut, and washer from the spout shank.
- □ Ensure that the seal gasket or O-ring is installed to the underside of the spout.
- □ Fit the spout shank through the top of the lavatory.
- □ Install the washer and nut onto the spout shank. Tighten the nut with a wrench to secure.
- □ With the screen cone facing downward, insert the rubber screen gasket and nylon washer into the tee. Thread the tee onto the spout shank.
- □ Hold the spout in position and tighten the tee securely. Do not overtighten!
- □ If desired, apply a bead of 100% silicone sealant or caulk around the base of the spout.

### **INSTALLATION INSTRUCTIONS**



## **INSTALLATION INSTRUCTIONS**



## **INSTALLATION INSTRUCTIONS**



### **INSTALLATION INSTRUCTIONS**



□ Pull up to remove the handle and bearing from the escutcheon.

NOTE: Use a pick or a similar tool to help remove the spline adapter.

- □ To adjust the handle, remove the screw and reposition the spline adapter.
- □ Reinstall the screw. Ensure that the valve is fully turned to the OFF position.

NOTE: To test the handle alignment, the handle does not need to be fully installed.

- □ Insert the handle until it engages with the spline adapter to verify alignment.
- □ Repeat this procedure until the desired handle alignment is obtained then push the handle down until it snaps firmly in place against the escutcheon.
- □ To adjust the escutcheon, loosen the screws in the ring to allow for escutcheon adjustment.
- □ Tighten the screws when desired escutcheon alignment is obtained.