


**OLD STYLE**  
**Manufactured 2010-April 2013**



4515 East 139th Street  
 Grandview, MO 64030  
 (800) 362-9055  
 Fax (800) 362-1463  
 www.PRIER.com


## P-164/264 Series Freezeless Wall Hydrant



- Freezeless
- Anti-Siphon
- Backflow Check Valve



Replacement Parts and Stems



ID	Part No.	Description
1	See Below	Stem Assembly, Contains: 1, 4, 10
2	300-1008	Valve Stem Cap
3	P-164KT-805	Oval Handle and Screw Kit
4	C-134KT-802	Seat Washer Kit (00 Beveled)
5	C-134KT-803	Stem Packing Replacement Kit
6	310-1015	Valve Stem Cap for Loose Key
7	390-1001	Stem Packing Only
8	C-108KT-808	Oval Style Key on Lanyard
9	C-144KT-806	Vacuum Breaker Replacement Kit
10	336-0002	Backflow Check Valve for C-144
	C-134KT-804	Loose Key Conversion Kit Contains: 5,6,8
	P-164KT-807	C-144 Overhaul Kit Contains: 3, 4, 5, 9, 10



**F Style Manufactured 2010 - April 2013**

Part No.	Style	Description	Stem Length
231-05CC	F	Close Coupled Stem for P-164 Hydrant	4 <sup>7</sup> / <sub>16</sub> " OAL
231-0504	F	Stem for 4" P-164 Hydrant	6 <sup>15</sup> / <sub>16</sub> " OAL
231-0506	F	Stem for 6" P-164 Hydrant	8 <sup>15</sup> / <sub>16</sub> " OAL
231-0508	F	Stem for 8" P-164 Hydrant	10 <sup>15</sup> / <sub>16</sub> " OAL
231-0510	F	Stem for 10" P-164 Hydrant	12 <sup>15</sup> / <sub>16</sub> " OAL
231-0512	F	Stem for 12" P-164 Hydrant	14 <sup>15</sup> / <sub>16</sub> " OAL
231-0514	F	Stem for 14" P-164 Hydrant	16 <sup>15</sup> / <sub>16</sub> " OAL
231-0516	F	Stem for 16" P-164 Hydrant	18 <sup>15</sup> / <sub>16</sub> " OAL
231-0518	F	Stem for 18" P-164 Hydrant	20 <sup>15</sup> / <sub>16</sub> " OAL
231-0520	F	Stem for 20" P-164 Hydrant	22 <sup>15</sup> / <sub>16</sub> " OAL
231-0522	F	Stem for 22" P-164 Hydrant	24 <sup>15</sup> / <sub>16</sub> " OAL
231-0524	F	Stem for 24" P-164 Hydrant	26 <sup>15</sup> / <sub>16</sub> " OAL
231-05US	F	*Universal Replacement Stem for P-164 Hydrant	

PRIER Universal Stems are replacement stems for any size from Close Coupled to 14". They require cutting the rod to proper length and soldering the brass stem end to the rod as directed in instructions.