

MINI-SPLIT MAINTENANCE KIT

- Easy-to-use kit that contains service and maintenance products
- Includes everything required to clean and service up to 4 mini-splits
- Ensures mini splits are clear and free of dirt and debris
- Complete Care Mini-Split Kit includes
 - (2) Tri-Pow'r® HD Aerosol 4371-75
 - (2) Gel Tabs™ Mini packs 4185-95
 - (1) Clean Guard™ Maintenance Bag 4150-01
 - (1) Nu-Calgon service bucket

Description

The Complete Care Mini Split Kit is a ready-to-use kit that includes everything you need to start cleaning and servicing mini-split systems. The kit includes (2) Tri-Pow'r® HD Aerosol cans 4371-75, (2) sets of Gel Tabs™ Mini 4185-95, (1) Clean Guard™ Maintenance Bag 4150-01, and (1) Nu-Calgon service bucket. The Complete Care Mini-Split Kit provides you with what you need to clean and service up to four mini-split systems.

Application

The Complete Care Mini-Split Kit makes cleaning and servicing mini-splits easy by providing a complete line-up of necessary chemicals and tools. The Clean Guard bag ensures that the surrounding area is protected from potential over-spray or water splashes. The provided Tri-Pow'r HD guarantees the mini-split is properly cleaned and brought back to peak efficiency, while the Gel Tabs Mini provide lasting protection from clogs and costly over flows.

Packaging

Complete Care Mini Split Kit **4151-18**

Directions for Use

STEP 1:

- Disconnect power from the unit.
- Remove the return filters and protective cover off the mini-split indoor unit.
- Simply snap the industrial elastic collar around the indoor coil. Important: Make sure the adjustable collar fits well to create a workable seal around the unit so as not to cause damage when cleaning the coil/blower followed by a power water wash if necessary.
- IMPORTANT: The Clean Guard does not cover exposed electronics. Please be sure to protect any electronics when cleaning with a cleaner and if pressurized water is used.
- Position the five-gallon bucket on a stable surface, typically the floor in most cases, and position the Clean Guard funnel into the bucket.

Indoor Air Quality Products

CompleteCare Mini-Split Kit



STEP 2:

- Shake Tri-Pow'r HD aerosol well before using.
- Remove cap and point toward surface to be cleaned.
- IMPORTANT: Do not spray electrical components.
- While cleaning with Tri-Pow'r HD aerosol, keep an eye on the five-gallon bucket to make sure cleaner/water is draining into bucket properly; resolve any kinks in the Clean Guard as necessary.
- Thoroughly saturate the target areas with the Tri-Pow'r HD aerosol. Be sure foam evenly covers the entire surface.
- Allow the cleaner to sit for 5-6 minutes, it is not necessary to rinse – the condensate will rinse the coil when the unit is powered on.

STEP 3:

- Place the Gel Tabs Mini inside the unit in the condensate pan on the inside of the inner edge of the drain pan, away from the condensate drain line opening.
- As the evaporator fins begin to sweat with condensate, the Gel Tabs Mini will slowly dissolve treatment into the drain pan, preventing sludge, odors, and overflows.
- Gel Tabs Mini are sized to treat up to 1.5 Tons per tab.
- The Gel Tabs Mini will provide preventative treatment for 3 months depending on the amount of condensate your unit produces.

STEP 4:

- Return the unit to service by powering on the mini split.
- Safely empty the contents of your bucket and ensure the Clean Guard bag is empty and not holding any excess chemical.
- Return the Clean Guard bag and remaining products to the bucket for future use.

NOTE: Read and understand the product's label and Safety Data Sheet ("SDS") for precautionary and first aid information. The SDS is available on the Nu-Calgon website at www.nucalgon.com.