


## **Product** Instructions




## SVC Compression Coupling 3/8"- 5/8"










- 1. Square off tubing to proper length. Slide compression nut up tubing and slip brass ferrule over tubing.
- 2. Slide tubing over end of SVC adapter, pushing it on fully until tubing is flush with shoulder of fitting.
- 3. Insert adapter into SVC coupling and tighten compression nut to SVC coupling to secure adapter. Re-tighten compression nut slightly after 30 mins.
- 4. Repeat the same procedure for the other side of the SVC compression coupling.


301 N. Main, 9th Floor • Wichita, KS 67202 • Ph: 800-976-9819 • Fax: 316-425-7618 • www.viega.com


## **Product** Instructions




## **SVC Compression Coupling 3/4"**









- 1. Tighten threaded adapter onto SVC coupling.
- 2. Square off tubing to proper length. Slide compression nut up tubing and slip brass ferrule over tubing. Slide tubing over end of SVC adapter, pushing it on fully until tubing is flush with shoulder of fitting.
- 3. Insert adapter into SVC coupling and tighten compression nut to secure adapter. Re-tighten compression nut slightly after 30 mins.
- 4. Repeat the same procedure for the other side of the SVC compression coupling.

301 N. Main, 9th Floor • Wichita, KS 67202 • Ph: 800-976-9819 • Fax: 316-425-7618 • www.viega.com